


TH500

Temperature and Humidity Controller

MANUAL

Thank you for the purchase of HANYOUNG product.
Please read this manual carefully.



nux
HANYOUNG

HEAD OFFICE
1381-3, Juan-Dong, Nam-Gu Incheon, Korea
TEL: (+82 32)876 - 4697 FAX: (+82 32)876 - 4696
<http://www.hynux.net> E-mail: mkt@hyelec.co.kr

MA0801E080125

HANYOUNG nux

Notice

This user guide is protected by copyright and has all the rights related to it. Without prior authorization from HANYOUNG, this guide and any parts contained in this guide cannot be reproduced, copied, or translated in another language.

Contents of this guide will be provided in this form and can be edited or changed without prior noticed.

This guide includes implied guarantee or suitability for a certain purpose, and it does not offer any guarantee for those that do not limit this matter.

Every programs contained in this product is protected by copyright. Without prior authorization from

HANYOUNG, this product and any parts contained in this product cannot be reproduced, copied, or translated in another language.

Every title, symbols, figures, service marks, and etc in this guide or the product are legally registered.

HANYOUNG NUX

#1381-3, Juan 5-dong, Nam-ku, Incheon, Korea

TEL: +82 32 876 4697 FAX: +82 32 876 4696

<http://www.hynux.net>

Contents

1. BEFORE STARTING	1.1 CHECKING PRODUCTS 1.2 SAFETY INFORMATION
2. INSTALLATION INSTRUCTION	2.1 INSTALLATION PLACE AND CAUTION NOTICE 2.2 INSTALLATION METHOD 2.3 SUFFIX CODE 2.4 DIMENSIONS / PANEL CUTOUT AND TERMINAL ARRANGEMENT 2.5 CONNECTION METHOD
3. SETTING AND OPERATION	3.1 INITIAL SCREEN 3.2 BASIC INPUT METHOD 3.3 NAMES OF EACH PART ON THE OPERATING SCREEN 3.4 RUNNING OF FIX CONTROL 3.5 RUNNING OF PROGRAM CONTROL 3.6 P.I.D AUTO TUNING 3.7 GRAPH DISPLAY AND SETTING 3.8 ERROR INDICATION
4. DISPLAY	4.1 OPERATING SCREEN 4.2 FUNCTION SETTING SCREEN 4.3 SYSTEM SETTING SCREEN
5. FUNCTION SETTING	5.1 OPERATING METHOD SETTING 5.2 PROGRAM SETTING 5.3 DATE/TIME RESERVATION SETTING 5.4 GRAPH/SAVE SETTING
6. SYSTEM SETTING	6.1 SENSOR TYPE SETTING 6.2 CONTROL OUTPUT SETTING 6.3 RETRANSMISSION OUTPUT SETTING 6.4 INNER SIGNAL AND ALARM SETTING 6.5 P.I.D SETTING 6.6 DIGITAL INPUT (D.I) CONFIGURATION SETTING 6.7 DIGITAL OUTPUT (D.O) CONFIGURATION SETTING 6.8 COMMUNICATION SETTING 6.9 OTHER SETTINGS
7. SIMPLE EXAMPLE	7.1 INPUT/OUTPUT SETTING 7.2 OUTPUT SETTING 7.3 INNER SIGNAL SETTING 7.4 FIX CONTROL 7.5 PROGRAM CONTROL
8. SPECIFICATION	8.1 INPUT 8.2 OUTPUT 8.3 COMMUNICATION TYPE 8.4 POWER SUPPLY 8.5 FUNCTION 8.6 OPERATION ENVIRONMENT 8.7 TRANSPORTATION AND STORAGE CONDITIONS

1 Before starting

Thank you for the purchase of HANYOUNG Temperature and Humidity Controller (Model# TH500).

This manual contains the function of product, install method, caution information and the way of using this controller. So please read this manual before using it. And also please make this manual to be delivered to the final user and to be placed where can be found and seen easily


(Contents of this user manual can be edited without prior notice for improvement and modification of the product.)

1.1 Checking products

After purchasing our product, please check if it is correct item you want. Also please check breakage on exterior and omission parts.


If it is a different controller which you want or you find omission parts, please contact our sales office.

1.1.1 TH500 Standard type (TH500-1NN)




1.1.2 TH500 additional type (with I/O Board)


● TH500 - 21N



● TH500 - 24N




● TH500 - 25N




1.1.3 TH500 Sale separately


- TH500 - 2NN (※ Attention) is a additional type




- TH500 - N1N



- TH500 - N2N



- TH500 - N3N



1.2 Safety information

1.2.1 Safety notice

- For safety and security of the system that is connected to the product, please read and follow this manual carefully.
- We are not responsible for any damages and safety problems due to disregards of the manual or lack of care of the product.
- Please install any extra safety circuitry or other safety materials outside the product for safety of the program that is connected to the product.
- Do not disassemble, repair or reconstruct the product. It can cause electric shock, fire, and errors.
- Do not give impact to products. It can cause of damage or malfunction.

1.2.2 Quality guarantee

- Unless it is included company's conditions for warrantee, we are not responsible for any warranties or guarantees.
- We are not responsible for any damages and indirect loss of the use or third person due to unpredicted natural disasters.

1.2.3 Quality guarantee conditions of product

- The warranty for this product is valid for 1 year from purchase, and we will fix any breakdowns and faults from proper uses as it is mentioned in this manual for free.
- After the warranty period, repair will be charged according to our standard policies.
- Under following conditions, repair will be charged even during warranty period.
 - Breakdowns due to user's misuses
 - Breakdowns due to natural disasters
 - Breakdowns due to moving the product after installation.
 - Breakdowns due to modification of the product
 - Breakdowns due to power troubles
- Please call our customer service for A/S due to breakdowns.

2. Installation Instruction

This is information for installation place and method of TH500 temperature and humidity program controller. So please read it before installation.

2.1 Installation place and caution notice

2.1.1 Installation place

To avoid electric shock, please use it after installation to panel.

Please avoid installing the product for following places where

People can touch terminal unconsciously

Directly exposed to the mechanical vibration or impact.

Exposed to the corrosive gas or combustible gas.

It is exposed to mechanical shock or vibration

Danger of corrosion or combustion of gas exist

Temperature changes too frequently

Temperature is either too high or too low

It is exposed to direct rays

It is exposed to electromagnetic waves too much

Humid place

It has many combustible objects

It has dusts and salinity

2.1.2 Caution

- The case of this controller is chrome-zinc plating and Bezel is made by ABS/PC anti-combustion material but please do not install it to the inflammable place.

Especially please do not put it on the inflammable products.

- Please keep it away from the machine or wires that can be cause of noise.

Especially, please have enough warm-up when you operate it under 10 °C temperature.

- Please install it on horizontally

- When you wire it, please cut out all of electric power.

- This controller is operating in 100 V ~ 240 V a.c, 50 ~ 60 Hz without additional change. If you use other voltage, it may cause of fire and electric shock.

- Do not operate controller with wet hand, it may cause of electric shock.

- Please follow Safety Information to prevent any fire, electric shock and any damage.
- Please follow this manual for install and operation of this controller.
- When you put to earth, please refer to install method. But do not connect earth to gas pipes, phone lines and lightning rods.
- Please do not turn on power until you install all of parts
- Please do not block ventilating windows. It may cause of break down.
- The grade of over voltage is Catalogue II and using environment is Degree II


2.2 Installation method

(1) Please use 1mm~10mm thickness of a steel sheet for panel.

(2) Please push TH500 in front of panel.

(3) Please fixate TH500 by fixing bracket.

(4) When you fixate TH500 to panel by fixing bracket, please do not tighten it too much. It may cause of break a panel or fixing bracket.



⚠ Caution

- To prevent electric shock, please check whether power has turned off or not.
- Before turn on power, please use more than third class grounding.
- When electricity transmits, it may cause electric shock so please do not touch terminal.
- Please wire it after turn off main power
- Please use around 2A fuse to main electronic power line.

2.3 Suffix Code


Code #	Suffix Code	Description
TH500		Temperature-Humidity Program Controller
TYPE	N	NONE
	1	STANDARD TYPE SENSOR INPUT: TEMPERATURE (Pt 100 Ω / 0-5 V d.c) HUMIDITY (Pt 100 Ω / 0-5 V d.c) DIGITAL INPUT (D.I): 8 POINT CONTROL OUTPUT: TEMPERATURE (SCR/SSR 1 POINT) HUMIDITY (SCR/SSR 1 POINT) RETRANSMISSION: TEMPERATURE (4-20 mA d.c 1 POINT) HUMIDITY (4-40 mA d.c 1 POINT) CONTACT OUTPUT: RELAY (1a1b) 4 POINTS RELAY (1a) 8 POINTS TRANSISTOR OUTPUT: OPEN COLLECTOR 8 POINTS COMMUNICATION: RS232C, RS485, USB
	2	ADDITIONAL TYPE SENSOR INPUT: TEMPERATURE ((Pt100 Ω / 0-5 V d.c) HUMIDITY (Pt100 Ω / 0-5 V d.c) RETRANSMISSION: TEMPERATURE (4-20 mA d.c 1 POINT) HUMIDITY (4-40 mA d.c 1 POINT) COMMUNICATION: RS232C, RS485, USB
OPTION	N	NONE
	1	I/O BOARD 1 SMPS (24V d.c, 18W) + D.I 8 POINT + RELAY (1a1b:4+1a:8) 12 POINTS
	2	I/O BOARD 2 O.C 8 POINT
	3	I/O BOARD 3 RELAY (1a1b) 8 POINTS I/O BOARD 1 + I/O BOARD 2
	4	SMPS (24V d.c, 18W) + D.I 8 POINTS + RELAY (1a1b:4+1a:8) 12 POINTS 12 POINTS + O.C 8 POINTS I/O BOARD 1 + I/O BOARD 3
	5	SMPS (24V d.c, 18W) + D.I 8 POINTS + RELAY (1a1b:4+1a:8) 12 POINTS 12 POINTS + RELAY (1a1b) 8 POINTS
COMMUNICATION	N	NONE
	1	ETHERNET (PREPARING)

※ There is No option for the STANDARD TYPE


2.4 Dimensions/ Panel cutout and Terminal arrangement

2.4.1. TH500 Standard type / Additional type


[Unit: mm]




2.4.2. TH500 Additional type I/O board 1



2.4.3. TH500 Additional type I/O board 2




2.4.4. TH500 Additional type I/O board 3




2.4.5 TH500 Standard type terminal arrangement

● TH500 Standard type terminal arrangement




● TH500 Additional type terminal arrangement




2.5 Connection method

2.5.1. Power

- Grounding needs more than 2mm² wire and at least the third class grounding connection (Grounding resistance below 100 Ω)




2.5.2. Sensor Input




Caution

- Please use input wire with shield. And the shield needs to have 1 point grounding.
- Please leave a space for Sensor line against power line or grounding line.

RTD (Resistance Temperature Detector) input (Pt 100 Ω)




Direct/Voltage input (0-5V d.c, 4 - 20 mA d.c)



※ If you use voltage input, please contact 250 Ω±0.1% resistance to the input terminal.


2.5.3. Temperature & Humidity control output and retransmission arrangement.




Caution

- Please pay attention when you connect it in polarity of output.
- Please use shield line for output line. And shield needs 1 point ground.

Temperature-Humidity controller output




Temperature-Humidity retransmission output (4-20mA d.c)




● External output arrangement


- Relay output



- Relay output



- Open collector output
TH500 separate body has 2 I/O BOARD




● Contact input & Digital input (D.I)


Please use non-voltage contact as like a Relay.

When you use open collector, the voltage of both of ends should be below 2V and the leakage voltage should be below 100 μ A in ON contact.

- In case of contact input (DI: 1 ~ 8)




- In case of transistor input (DI: 1 ~ 8)





Retransmission arrangement

- RS232C arrangement (Base on connector 9 pins)



- RS422/RS485 arrangement

TH500 can contact to maximum 32 machines. Please contact Terminating Resistance (100 ~ 200 Ω 1/4 W) to the both of ends of retransmission lines.



3. Setting and operating

3.1. Initial screen

When the TH500 power is on, the screen for logo indication (Fig.1) and screen for system check (Fig.2) will be appear in order of precedence.

(Users can change the screen for logo indication and system check.)



(Fig.1) Logo screen



(Fig.2) Screen for system check

3.2. Basic Input Method

Table 1) Button & Input Box

	Name	Function
	Select button	Users can select this button on their demand. If you press this button, its color will turn into another. By releasing it back, you can select this button operation.
	Active input box (Input available)	Users can enter various set values into this box as they wish. When you press the box, a certain range of numbers or the text input box (Fig.4 to Fig.7) will appear depending on situations. Then, you have only to press the set value.
	Inactive input box (Input unavailable)	This box is inactive under current conditions or situations. However, if you put it under certain conditions or situations, it will turn into the active input box as shown above.

3.2.1. Screen for button input

The Fig. 3 is the basic number input box. You can enter integral numbers or real numbers (Decimal point) there. The title of an entered number and its upper and lower limits will be indicated on the left top of the box. The current input value will be indicated at the indication box over the figure board. The entered number will be entered completely only if you enter the **ENT** (Fig.3) is the basic number input box key. You can cancel the entered content by pressing the **ESC** key.



(Fig.3) is the basic number input box

3.2.2. Number / Korean / English / Sign Input

Fig. 4 to 7 shows the screen for entering the Number/Korean/English/Sign. This multi-input screen enables you to enter the Number/Korean/English/Sign text respectively by pressing the **CHANGE KEYPAD** key in turn. Its shift order is: **Number Input Mode** → **Korean Input Mode** → **English Input Mode** → **Sign Input Mode**. You can return to the **Number Input Mode** by pressing the **CHANGE KEYPAD** key. The arrangements of Number/Korean/English/Sign keyboards are different from each other. However, the Function keys on the right side play the same roles as follows.


- **CLR** : Delete all the current texts entered.
- **←** : Delete one letter ahead of the current cursor.
- **ENT** : Save the text indicated up to the current cursor into the internal memory.

After typing the text based on the combination of keys and functions, you can save all the texts completely by pressing the **ENT** key. As they save completely, you will be also escaped from the multi input screen. If you are to cancel the text, you can press the **ESC** key on the right top side. By doing so, you can delete all the current text while escaping the input box.

User can input program pattern name as followings **MENU** → **PROGRAM SETUP** → **PROGRAM NAME SETUP** → **PATTERN NUMBER** .

3.2.3. Number Input Mode

The screen for number input is shown in the Fig.4. If you press the number 0 to 9 and . keys once, they will be indicated on the cursor position. Whenever you press the ([,]), [%], [₩] and [+/-] keys on the left side of the keyboard, they will be indicated in turn. When you press such duplicate keys, the cursor will not move at all while waiting for continuous entry. At that time, if a certain period of time (approx. 1 second) passes, the cursor will move automatically to the next position disabling you from continuous entry.



(Fig. 4) The screen for number input

Ex) If you want to indicate 1. (The _ on the bottom indicates a flickering cursor.)

fU Operation: [1]
fU Result: 1_

Ex) If you want to indicate 123.45. (The _ on the bottom indicates a flickering cursor.)

fU Operation: [1]+[2]+[3]+[.] + [4]+[5]
fU Result: 123.45_

Ex) If you want to indicate [.

fU Operation: ([.) + ([.) (Press twice within one second.)


fU Result: [.]_ (The _ on the bottom indicates a flickering cursor.)

fU Operation: One second passed after the ([.) key is pressed once.

fU Result: [.]_ (The _ on the bottom indicates a flickering cursor.)

3.2.4 Korean Input Mode

The screen for Korean input is shown on the Fig. 5. All the keys except the [.), ([.), [<], [>] keys consist of duplicate keys. There is also an additional function key [çi]. The principle of using function keys is the same in every mode. If you want to enter double consonants such as <ç, <ç, <ç, <ç, <ç, you should press the consonant three times. You should press the [çi] key, if you go to the next letter while entering letters.



(Fig. 5) The screen for Korean input

Or you can also use such key when entering the blank. The Korean alphabet consists of three elements such as an initial consonant, a medial vowel and a final consonant. This input mode is classified into consonants and vowels, so the consonants are not divided into an initial and final one. Therefore, you have only to enter an appropriate consonant regardless of its initial or final position. The medial vowel consists of vowels only, so you have only to press an appropriate vowel.

Ex) If you want to indicate i [çi]

fU Operation: [ç] + [çi]

fU Result: <ç_ (The _ on the bottom indicates a flickering cursor.)

Ex) If you want to indicate i [çi]

fU Operation: [ç] + [çi] + [çi]

fU Result: <ç_ (The _ on the bottom indicates a flickering cursor.)

Ex) If you want to indicate i [çi]

fU Operation: [ç] + [çi] + [çi] + [çi]

fU Result: <ç_ (The _ on the bottom indicates a flickering cursor.)

Ex) If you want to indicate i [çi]

fU Operation: [ç] + [çi] + [çi]

fU Result: [çi]_ (The _ on the bottom indicates a flickering cursor.)

Ex) If you want to indicate i [çi]

fU Operation: [ç] + [çi] + [çi] + [çi]

fU Result: [çi]_ (The _ on the bottom indicates a flickering cursor.)

Ex) If you want to indicate i [çi]

fU Operation: [ç] + [çi] + [çi] + [çi]

fU Result: [çi]_ (The _ on the bottom indicates a flickering cursor.)

Ex) If you want to indicate i [çi]

fU Operation: [ç] + [çi] + [çi] + [çi] + [çi]

fU Result: [çi]_ (The _ on the bottom indicates a flickering cursor.)

fU Operation: [ç] + [çi] + [çi] + [çi] + [çi]

fU Result: [çi]_ (The _ on the bottom indicates a flickering cursor.)

fU Operation: [ç] + [çi] + [çi] + [çi] + [çi]

fU Result: [çi]_ (The _ on the bottom indicates a flickering cursor.)

Ex) If you want to indicate i [çi]

fU Operation: [ç] + [çi] + [çi] + [çi] + [çi]

fU Result: [çi]_ (The _ on the bottom indicates a flickering cursor.)

fU Operation: [ç] + [çi] + [çi] + [çi] + [çi]

fU Result: [çi]_ (The _ on the bottom indicates a flickering cursor.)

fU Operation: [ç] + [çi] + [çi] + [çi] + [çi]

fU Result: [çi]_ (The _ on the bottom indicates a flickering cursor.)

3.2.5. English Input Mode

The screen for English input is shown on the Fig. 6. All the keys except the **.** and **,** keys consist of duplicate keys. Its basic use is the same as that of the Korean input mode.



(Fig. 6) The screen for English input

Ex) If you want to indicate: **B i**:-

fUOperation: **.** + **,**

fUResult: B _ (The _ on the bottom indicates a flickering cursor.)


Ex) If you want to indicate: **OPER i**:-

fUOperation: **.** + Wait for one second + **,** + **.** + **,** + **.** + **,** + **.**

fUResult: OPER _ (The _ on the bottom indicates a flickering cursor.)

3.2.6. Sign Input Mode

The screen for sign input is shown on the Fig. 7. All the keys except the **.** key consist of duplicate keys. Its basic use is the same as that of the English input mode.



(Fig. 7) The screen for sign input

Ex) If you want to indicate: **& i**:-

fUOperation: **.** + **,**

fUResult: & _ (The _ on the bottom indicates a flickering cursor.)

Ex) If you want to indicate: **((1+2) X 3) = 9 i**

fUOperation: **(** + Wait for one second + **(** + **(**

Keyboard Shift + **1** + **+** + **2** + **)** + **)** +


≡ + **i** + **3** + **)** + **)** +

Keyboard Shift + **Keyboard Shift** + **Keyboard Shift** + **=** +

Keyboard Shift + **9** + **i** + **%**

fUResult: ((1 + 2) X 3) = 9 i _ (The _ on the bottom indicates a flickering cursor.)

3.3. The name of each part on the operating screen



(Fig. 8) The 1st running screen of fix control


- | | |
|----------------------------------------------------|---------------------------------------|
| 1. Current operation status | 11. Current date/time |
| 2. Menu button | 12. Temperature PV Up/Down indication |
| 3. Operation screen 2 shift button | 13. Temperature SV input box |
| 4. Run/Stop indication | 14. Humidity PV Up/ Down indication |
| 5. Control output BAR for current temperature (MV) | 15. Humidity SV input box |
| 6. Current temperature PV | 16. Running time indication |
| 7. Control output BAR for current humidity (MV) | 17. Temperature A/T button |
| 8. Current humidity PV | 18. Humidity A/T button |
| 9. Temperature PID Zone No. input box | 19. Start button for Fix control |
| 10. Humidity PID Zone No. input box | 20. Stop button for Fix control |

i 17, 18 are displayed only in operation.



Attention

After pressing the **RUN** button, you are unable to press various setting buttons like MENU or input boxes, because they may have a serious effect on system control operations.




(Fig. 9) The 1st running screen of program control

- | | |
|----------------------------------------------------|---------------------------------------|
| 1. Current operation status | 11. Temperature SV Up/Down indication |
| 2. Menu button | 12. Start pattern No. input box |
| 3. Operation screen 2 shift button | 13. Humidity SV Up/Down indication |
| 4. Running/Stop indication | 14. Start segment No. input box |
| 5. Control output BAR for current temperature (MV) | 15. Running time indication |
| 6. Current temperature PV | 16. Current operating pattern No. |
| 7. Control output BAR for current humidity (MV) | 17. Current operating segment No. |
| 8. Current humidity PV | 18. Program STEP button |
| 9. Operation pattern name | 19. Program HOLD button |
| 10. Current date/time | 20. Program operation Start button |
| | 21. Program operation End button |


i □ 16~19 are displayed only in operation

The operation screen 1 (Fig. 8, Fig. 9) is the basic screen where you can enter either temperature & humidity setting value (SV) or start pattern/loop No. in the Fix/Program mode. After entering your desired setting value, you can press the **RUN** button to start control.



(Fig.10) The 2nd running screen of program control

- | | |
|--------------------------------------|-----------------------------------------------------------------------------------------------------------|
| 1. Current operation status | 17. Current humidity MV |
| 2. Menu button | 18. Temperature/humidity Up/Down section indication |
| 3. Operation screen 3 shift button 1 | 19. Temperature/humidity holding section indication |
| 4. Running/Stop indication | 20. Temperature/humidity waiting indication |
| 5. Temperature PID ZONE No. | 21. Running time indication |
| 6. Current temperature PV | 22. Buttons for system error indication |
| 7. Current temperature SV | 23. Current operation pattern/ segment indication (pattern No./segment No.) |
| 8. MV | 24. Current pattern repeat No. indication (Current repeat No./Entire repeat count) |
| 9. I/S signal status indication | 25. Current operation section / repeat info. Indication Current section repeat No. / Section repeat count |
| 10. T/S signal status indication | |
| 11. D/I signal status indication | |
| 12. A/S signal status indication | |
| 13. SEG. running time indication | |
| 14. Humidity PID ZONE No. | |
| 15. Current humidity PV | |
| 16. Current humidity SV | |




(Fig.11) Screen for graph view

- | | |
|---------------------------------------------|------------------------------------------------------|
| 1. Current operation status | 11. Current temperature PV indication |
| 2. Menu button | 12. Current temperature MV/SV indicator shift button |
| 3. Operation screen 1 shift button | 13. Current temperature MV or SV indication |
| 4. Running/Stop indication | 14. Current humidity PV indication |
| 5. Upside screen of Y axis | 15. Current humidity MV or SV indication |
| 6. Temperature & humidity SV, PV indication | 16. Current humidity MV/SV indicator shift button |
| 7. Div time increase of X axis | 17. Y axis temperature & humidity unit shift button |
| 8. Div time decrease of X axis | 18. Y axis unit indication |
| 9. X axis time / Div | 19. Graph/Save setting button |


3.4. Running of Fix-control

Fix-control is running a temperature and humidity by fixed set value (SV).

3.4.1. Running selection of Fix-control 1.



(Fig.12) The 1st running screen of Fix control (Stop screen)



(Fig.13) The 1st running screen of Fix control (Run screen)

Start running : You can start the fixed running just by entering a temperature & humidity setting value (SV) and pressing the **RUN** button in the 1st running screen of Fix control(Fig. 12). In this case, the arrow indicator will move to indicate its running status, while the indicator on the right bottom will be changed into the **RUN** button with its red color.

Stop running : Press the **STOP** button if you want to stop running.

Fix-control or Program control (Fig.12) can be selected from Main Menu, if you press the **MENU** button in the 1st running screen of Fix control. In the Main Menu, press the **FUNCTION SETUP** button and select Running mode. Fix control will be selected by press the **FIXRUN** button. Press the **NEXT** button to set an each setting item of the 2nd function set up screen.

Whenever you change the setting value (SV) during its running, the PID ZONE numbers for controlling will change automatically. If you want to use a particular PID ZONE number, you should enter a ZONE number again after entering a setting value. After starting the operation, both **TAT** and **HAT** buttons will become the temperature and humidity Auto Tuning (A/T) buttons respectively. A/T is available only in the Fix-Running mode. You can execute this A/T by entering its necessary temperature or humidity setting value (SV) and pressing its related button. If you want to stop A/T, you should press its operating button. In other words, you should press the **TAT** button for temperature, but press the **HAT** button for humidity again. Of course, you can also stop AT process by pressing the **STOP** button of fix control

while stopping the controlling operation. In this case, all the operation values related to A/T will not be saved. A/T can running up to 24 hour, beyond which A/T will stop.

Caution 1.

When it comes to temperature, its PV will be always displayed unless the sensor line is disconnected. However, as far as humidity is concerned, its PV will not be indicated unless a setting value (SV) is entered. If you set the SV to 0 and press the **RUN** button, you can control the temperature only.


Caution 2.

It is impossible to run A/T for temperature and humidity at the same time. Therefore, it is desirable to run humidity after maintaining a target temperature. The button concerned will flash during Auto tuning.


T.A.T	Temperature Auto Tuning button (Flash during running)
H.A.T	Humidity Auto Tuning button (Flash during running)

3.4.2. Running selection of Fix-control

Process value and Set value of temperature and humidity is shown basically in the 2nd running stop screen of Fix control. There is shown also for Inner signal(I/S), Time signal(T/S), Digital input signal(D/I), Alarm signal(A/S), and indicate a gradient of initial set value by form of UP/DN and SOAK.



(Fig.14) The 2nd running screen of Fix control (Stop screen)




(Fig.15) The 2nd running screen of Fix control (Run screen)


3.5. Running of Program control

Program control is control a Process Value (PV) by change of Set Value (SV) according to course of time. For example, it increase current temperature to 30 i □ for 10 min. and maintain 30 i □ for 15min., and then increase to 70 i □ again for 40 min. and maintain the 70 i □ for 1 hour. Program control is especially using widely in the test equipment for environment like as thermostat and electric furnace.

3.5.1. Selection of Program Control Running




(Fig.16) The 1st running screen of program control(stop screen)




(Fig.17) Main menu for function setup

In order to running with program control, press the **MENU** button of the top on the 1st running screen of program control (Fig.16) and move to the screen for function setting (Fig.17). Move to the screen **Function Setup 1 i** by press the **FUNCTION SETUP** button, and select the program control as running mode by press the **PROGRAM** button. After finish setting "FUNCTION SETUP 1 & 2 by press **NEXT** button, and move to **Main Menu i** screen by press **ESC** button. And then, finish the set for **DATE/TIME RESERVE SET i**, **GRAP / LOG SETUP i**, and move to the Program Set Screen (Fig.18) by **PROGRAM SETUP** button to set a program. Set an each item with press the buttons in the Program set screen (Fig.18).

3.5.2. Set of Program Control Pattern



(Fig.18) Program Set Screen



(Fig.19) Pattern Set Screen

Press the **PATTERN SETUP** button in the program set screen (Fig.18) and move to the screen for program pattern set (Fig.19). Establish the set item for each segment of pattern in the screen for program pattern set (Fig.20).

Move to the running stopped screen 1 for program control after input for all, and input a start segment No. in the pattern and program start pattern. And then, program control will be running if you press the **RUN** button.



(Fig.20) The 1st running screen of program control(Stop screen)




(Fig.21) The 1st running screen of program control(Run screen)

Once the program operation starts, STEP and HOLD buttons will appear newly like as running screen 1 for program control (Fig.21). These buttons has function which is related to progress of segment.

Button	Name	Function
STEP	Program STEP button	Stop the present segment within the current program pattern, and start the next segment.
HOLD	Program HOLD button	Keep running the current segment unlimitedly within the current program.

3.6. PID Auto Tuning.

Auto Tuning (hereinafter referred to as A/T) is the automatic setting function in which the controller measures the characteristics of the control system automatically and calculates the optimal PID values accordingly. The A/T method measures and calculates a cycle by producing the ON/OFF control output for the two cycles and generating the limit cycle of controlled targets.



(Fig 22) P.I.D Auto Tuning


You can execute A/T all the time by entering a target setting value (SV) in the fixed control mode, pressing the **RUN** button, and pressing the subsequent either **TAT** or **HAT** button. After A/T is finished normally, if the unit is set to automatic PID ZONE reference mode, the resulted PID value will be saved into the appropriate PID ZONE. If this unit is set to manual PID ZONE reference mode, the results PID value will be saved into your designated PID ZONE.

⚠ Caution


If A/T still runs in 24 hours after A/T execution, A/T operation will come to an end automatically. If you close the A/T operation by force during A/T process, the operating value will not be saved and maintained as a previous setting value.

3.7. Graph display and setting


The graph display screen is the screen that shows the SV and PV of a temperature and humidity in graph. You can change the X and Y axes respectively by pressing the **SETUP** button (You can set a time of the X axis, Max. and Min. range of the Y axis in the graph set screen, and select also a state of save operation like as **ALL ON**, **RUN ON**, **FIX ON**, **Prog ON**, and save period). And you can also display the Y axis for temperature range and humidity range by pressing the **AXIS** button.



(Fig.23) Screen for fix control graph display




(Fig.24) Screen for program control graph display



(Fig.25) Graph set screen

3.8. Error Indication

The second running screen of program control or fix control (Fig.26) is indicating an operating state for running.




(Fig.26) The 2nd running screen of program control



(Fig.27) Indication screen for occurrence of error

The indication of errors through sensor disconnection and external D/I is displayed with **ERROR** button on and off in the 2nd running screen of program control (Fig. 26). If you press the **ERROR** button, the error occurrence screen will appear. In this case, the error indicator for temperature & humidity disconnection will appear, while D/I(External contact input) no. 1 to 8 will be displayed on the bottom. You can check it by pressing the Up/Down arrow button.

Press the **NEXT** button to show the operating record indication screen which can check the state of RUN, STOP, Sensor Disconnection and External Contact Input (D/I).




(Fig.28) Operating Rec

4 Displays

Entire displays are mainly composed of three sections which are Working display, Function setting display(Included program installation) and System setting display.

4.1 Operating screen


After you finish to connect & turn on the power, Logo signal & System check display will be shown in a moment, and then Working display will be shown. In that time, according to selecting the initial setting program or Fixed driving method, it will be shown to Program control working display or Fixed control working display.




(Fig. 29)The 1st running screen of program control (Stop screen)




(Fig. 30)The 1st running stop screen of Fix control (Run screen)




(Fig. 31)The 2nd running screen of program control



(Fig. 32)The 2nd running screen of Fix control



(Fig. 33)Program control Graph screen




(Fig. 34)Fix control Graph screen

4.2 Function setting screen

After you push **MENU** button in working display condition, Function setting menu screen is shown. It is composed of 4 buttons. Push each button to set up under an item.




(Fig. 35)The 1st running screen of program control(Stop screen)



(Fig. 36)Main menu for function Set up

4.3 System setting screen




Caution

There is no need for System setting made separately by driver. Because the Basic setting condition of this system is set up by the operator, you should be careful especially .

As pushing **MENU** button in running screen, Main Menu screen is shown. Pushing the character of Main Menu in that time, Password input display is shown. Pushing **ENT** after inputting (initial value: 0), the display of System setting function menu shows. It is composed of 8 buttons.




(Fig.37) Password input screen




(Fig.38) System setting menu screen

5. Function setting

After finishing installation & connection, turn on the power. Logo and system checking are display one after other. And then (Fig.40)the 1st working stop screen of program control is displayed.



(Fig.39)The 1st running screen of program control (Stop screen)




(Fig.40)Main menu for function set up


5.1 Working method setting

5.1.1 Function Setup 1.

Pushing FUNCTION SET UP button in (Fig.40)Function set up menu screen and you can select or set up each setting item in the Function setup 1 screen. Choose Select Program control or Fix control in run mode.



(Fig.41)Function Set up 1 screen



(Fig.42)Function Set up 2 screen

Run mode	Program	Select in program control
	Fix	Select in fix control
T.SV variation	Set it up as the gradient of temperature variations [1□m] per hour (minute) from current temperature to setting temperature in fix control.	
H.SV variation	Set it up as the gradient of humidity variations [1□m] per hour (minute) from current humidity to setting humidity in fix control.	
Fix run time	After running the fix-mode control for the time entered, the operation will stop automatically.	
MV tracking	Manipulated Variable Tracking The drastic change of setting values will lead abrupt control output. To prevent it, MV tracking runs when set value (SV) changes over 1[5.0 1□	


5.1.2 Function set up 2

After finishing Function setup 1, press **NEXT** button to set up the item in Function set up 2. In case of outage due to a power failure, it runs according to the BOOT RUN on Function Setup 2. (But power recovers within 5 seconds after failure, the BOOT RUN condition is same as before power failure)


Fuzzy Function	At the beginning of running, MV (Measurement Value) may exceed SV (Set value). It is called 'Over Shoot'. To prevent Over Sheet, please use Fuzzy function. If you turn on Fuzzy function, the rising time may delay or under shoot may happen.		
Boot Run	Setting	Program control	Fix control
	Stop	Stop	Stop
	Cold	Start from the beginning	Start from same set value as before power failure
	Hot	Start from the segment before power failure	Run Start
Beep	Turn on/off the buzzer sound to check various input and operation.		
Touch PNL	It is used to limit the touch panel input during system control operating. If select lock, it is impossible to input except MENU , NEXT and RUN / STOP buttons.		
Screen P. Down	It is a function to turn off power of Back-Light in order to protect LCD display, If you input '0', the backlight turn on all the time.		

5.2 Program Setting

(Fig.41) Press **PROGRAM SETUP** button in Main menu screen, Program set up menu will be shown. It is composed of 5 buttons. Push button to set up each item.




(Fig.43) Main Menu for function Set up




(Fig.44) Program Set up Menu

5.2.1 Pattern setting

(Fig.44) Pushing **PATTERN SETUP** button in Program set up menu screen, Program pattern set up screen is indicated. Set segment of each pattern in this screen. Program control will run according to the content & sequence of segment designed.



(Fig.45) Program pattern set up screen



(Fig.46) Segment selection screen

Set up each input item (Fig.45) in reference of the diagram as toll owing

Name	Function	Range
Pattern No.	Enter a pattern number to set or select it by pressing Up/Down button.	1 ~ 300 pattern
SEG.Page	Press Up/Down button, it moves each 4 segment.	
Temperature SV	Press set up window, set Temperature SV of segment.	-100 ~ 200 °C
Humidity SV	Press set up window, set Humidity SV of segment	0 ~ 100 %

Hour/Minute	Setting operation time of segment	0 hour 0 minute ~ 255 hour 59 minute
Wait	Selecting waiting operation function set in waiting operation setting display.	ON/OFF
T.S.(Time Signal)	Selecting valid time signal in segment	
Alarm	Selecting each action among 4 kinds of signal assigned in pattern signal setting display. (Fig.48)Pattern signal selection screen	1~4 each On/Off

● SEG. Insert/Delete

Pressing SEG number in the left side of (Fig.45), User can Insert/Delete segment in Fig.46. SEG.. Page button is changed to **INS**, **DEL** button in that time. Pressing this button, Segment should be inserted or deleted and then the next Segment will be moved.

● Waiting/Pattern signal selection


Select Waiting, Pattern signal item of Program pattern setting display to execute contents set in Waiting Operation Setting display & Pattern Alarm Setting display (If you press **WAIT/ALARM SSV SETUP** button in Program setting display, Waiting Operation Setting display will be indicated.)




(Fig.47)Pattern Alarm selecting screen

5.2.2 Time Signal Set up

Pressing Time Signal(T.S.) in (Fig.45)Program Pattern Setting display, (Fig.48)Time Signal set up display will be shown.




(Fig.48)Time Signal Set up Display



(Fig.49)Example of Time Signal Set up

Time Signal Set up Mode is divided into 2 types according to mode: SEG On/Off Mode and Time Set up Mode. Time Signal can be set to 8 points per each Segment.

Setting Mode	Function	Setting Range
SEG On/Off Mode	Set the Time Signal in ON, while segment is operating	Each segment
Time	Set the Time Signal in ON, after setting time is delayed from the beginning of segment.	0 ~ 99 hour 59 min
(Time Setting Mode)	Set the Time Signal in ON, during setting time from segment in ON.	0~ 99 hour 59 min




(Fig. 50) Example of Time Signal ON/OFF mode

Time Signal(T.S)	Description
T.S 1	SEG. 2 ON under 50°C soak status
T.S 2	SEG. 4 ON under 25°C soak status
T.S 3	SEG. 6 ON under 75°C soak status
T.S 4	SEG. 1 and SEG.5 ON under Up section
T.S 5	SEG. 3 ON under Down section
T.S 6	SEG. 1 to SEG. 3 ON
T.S 7	SEG. 4 to SEG. 6 ON
T.S 8	SEG. 1 to SEG. 6 ON under program control running

(Fig.48) shows an example of using the T/S in ON/OFF mode. It performs turning on and off the T/S in the desired segment with the name of ON/OFF mode. The ON and OFF buttons are composed separately like (Fig.46). Select by pressing **ON** or **OFF** button, according to the desired Time Signal Operation.

● Example of Setting the Time Signal in TIME Set up mode



Time Signal	Description
T.S 1	When starting the SEG.1, it has T/S ON without a delay and OFF in two hours (On Time). When starting the SEG.6, T/S ON without a delay and OFF due to program ending though On Time is two hours.
T.S 2	When starting the SEG.1, it has T/S ON after delay (30 minutes) and OFF in two and a half hour (On Time). When starting the SEG.6, it has T/S ON after delay (30 minutes) and OFF in one hour (On Time).


(Fig.51) Example of Setting the Time Signal in TIME Set up mode

Time Signal	Description
T.S 1	When starting the SEG.3, it has T/S ON without delay and OFF in four hour (On Time).
T.S 2	In case of SEG.2, SEG.4 and SEG.6, it is T/S ON without delay and OFF after On Time.

Caution Time Signal will be OFF once the program ends regardless of setting modes.

5.2.3 Pattern repeat/Connect setting

Pressing **PROGRAM SETUP**, **Pattern REPEAT/LINK setup** button in (Fig.43) Main menu screen, (Fig.52) Pattern repeat/link set up is shown. If you set Current Pattern repeat count to Pattern repeat on the right side of the top and Current Pattern number to connect Pattern, Current pattern will be run in unlimited repeat according to Segment Operation. Program operation executes inputted segment in sequence basically, but it comes occasionally that the case of set segment contents in pattern should be repeated & executed. Using Section repeat in that time, reduce Program input as much as possible. You can move among Section repeat setting pages by using the **▲** **▼** buttons on the right side in the order ranging from 1 to 20 in total.



(Fig.52) Pattern repeat/Link set up

Name	Function	Range
Pattern NO.	Enter the pattern number to set or select it by pressing the Up/Down button.	1~300 Pattern
Pattern Repeat	1 ~ 300 pattern Pattern Repeat Enter the count of entered pattern number to repeat. When you want to have the pattern repeated unlimitedly, you should enter a current pattern number into the next pattern number below.	1 ~ 9,999 time
Pattern Link	After finishing pattern working, set a connect-working Pattern number. If you set to 0, Working will be completed without connect-Working.	0~300 pattern
NO	It indicates the serial numbers that users are unable to set. It offers total 20 Section repeats per pattern, and it executes them sequentially in the order ranging from 1 to 20 number.	1~20 number

Name	Function	Range
Initial SEG.	Set the initial segment number of Section repeat. If it is set to 0, it executes to the next Section repeat number.	0 ~ 100 SEG
Final SEG.	Set the final segment number of Section repeat. If it is set to 0, it executes to the next Section repeat number.	0 ~ 100 SEG
Section repeat	Set the count of current Section repeat. If it is set to 0, it executes to the next Section repeat number.	0 ~ 255 time

● The Segment operation sequence by Section repeat setting


If segment in pattern is set from 1 to 8, it operates like below according to Section repeat Setting.

	Section repeat serial number	Section repeat setting			Segment operation sequence
		Start	End	Repeat	
1	1 ~ 2 0	0	0	0	① → ② → ③ → ④ → ⑤ → ⑥ → ⑦ → ⑧
2	1	3	6	2	① → ② → ③ → ④ → ⑤ → ⑥ ③ → ④ → ⑤ → ⑥ → ⑦ → ⑧
					① → ② → ③ → ④ → ⑤ → ⑥ ③ → ④ → ⑤ → ⑥ ④ → ⑤ ④ → ⑤ → ⑥ → ⑦ → ⑧
3	1	3	6	2	① → ② → ③ → ④ → ⑤ → ⑥ ③ → ④ → ⑤ → ⑥ ④ → ⑤ ④ → ⑤ → ⑥ → ⑦ → ⑧
	2	4	5	2	① → ② → ③ ② → ③ ① → ② → ③ → ④ ① → ② → ③ → ④ → ⑤ → ⑥ → ⑦ → ⑧
4	1	2	3	2	① → ② → ③ ② → ③ ① → ② → ③ → ④ ① → ② → ③ → ④ → ⑤ → ⑥ → ⑦ → ⑧
	2	1	4	2	① → ② → ③ ② → ③ ⑥ → ⑦ ⑥ → ⑦ → ⑧
5	1	2	3	2	① → ② → ③ ② → ③ ⑥ → ⑦ ⑥ → ⑦ → ⑧
	2	6	7	2	① → ② → ③ → ④ → ⑤ → ⑥ → ⑦ ⑤ → ⑥ → ⑦ ② → ③ ② → ③ → ④ → ⑤ → ⑥ → ⑦ → ⑧
6	1	5	7	2	① → ② → ③ → ④ → ⑤ → ⑥ → ⑦ ⑥ → ⑦ ② → ③ ② → ③ → ④ → ⑤ → ⑥ → ⑦ → ⑧
	2	2	3	2	① → ② → ③ → ④ → ⑤ → ⑥ → ⑦ ⑥ → ⑦ ② → ③ ② → ③ → ④ → ⑤ → ⑥ → ⑦ → ⑧
7	1	6	7	2	① → ② → ③ → ④ → ⑤ → ⑥ → ⑦ ⑥ → ⑦ ② → ③ ② → ③ → ④ → ⑤ → ⑥ → ⑦ → ⑧
	2	2	3	2	① → ② → ③ → ④ → ⑤ → ⑥ → ⑦ → ⑧ ② → ③ → ④ → ⑤ → ⑥ → ⑦ ③ → ④ → ⑤ → ⑥ ④ → ⑤ ⑤ ⑤ ① → ② → ③ → ④ → ⑤ → ⑥ → ⑦ → ⑧ ① → ② → ③ → ④ → ⑤ → ⑥ → ⑦ → ⑧
8	1	1	8	1	① → ② → ③ → ④ → ⑤ → ⑥ → ⑦ → ⑧
	2	2	7	1	② → ③ → ④ → ⑤ → ⑥ → ⑦
	3	3	6	1	③ → ④ → ⑤ → ⑥
	4	4	5	1	④ → ⑤
	5	5	5	2	⑤ ⑤
	6	1	8	2	① → ② → ③ → ④ → ⑤ → ⑥ → ⑦ → ⑧ ① → ② → ③ → ④ → ⑤ → ⑥ → ⑦ → ⑧
	7	7	7	2	⑦ ⑦ → ⑧

* 20 times of section repeats are available for one pattern.


5.2.4 Waiting/Alarm start mode setting

Press **PROGRAM SETUP** **WAIT/ALARM S.SV SETUP** button in Main Menu to move Pattern wait Set up screen. Waiting operation can be set by each segment of proper pattern. In case that Waiting operation of Measurement value(MV) comes or fails to come within Waiting range of Set value(SV), wait process of segment during setting Waiting operation time and then go to next segment. (Only if Waiting operation is set to '0', Waiting operation will not work).



(Fig.53) Pattern wait set up


Name	Function	Range
Pattern No.	Enter a pattern number to be set or select it by pressing button.	1 ~ 300 pattern
Temp. Wait range	Enter a temperature range (absolute value) necessary for waiting temperature range. If you enter 0, the temperature waiting will be OFF.	0.0 ~ i□ 300.0 [i□]
Humi. Wait range	Enter a humidity range (absolute value) necessary for waiting humidity range. If you enter 0, the humidity waiting will be OFF.	0.0 ~ i□ 100.0%
Waiting time	Enter the maximum range of waiting time. If you enter 0 hour 0 minute, it will be set to the unlimited waiting time. If you set both temperature and humidity waiting ranges, the system will run under the AND condition. In other words, the waiting mode will be released, only when both ranges come within the waiting range.	0.0 ~ 99 hour 59 minute



SEG. running when the pattern waiting mode is not applied	SEG.1	SEG.2	SEG.3
SEG. running when the pattern waiting mode is applied	SEG.1	SEG.2	SEG.3

(Fig.54) Common waiting operation

(Fig.54) It shows common waiting mode operation. If the PV fails to enter into the waiting range at the point when the SEG.1 to SEG. 2, the system will wait for the PV to enter into the waiting range during the waiting time. According to the (Fig. 15), even if the PV fails to enter into the waiting range, the system will execute SEG. 2 unconditionally (Fig.55)




SEG. running when the pattern waiting mode is not applied	SEG.1	SEG.2	SEG.3
SEG. running when the pattern waiting mode is applied	SEG.1	SEG.2	SEG.3


(Fig.55) Waiting operation release due to the excess of waiting time

5.2.5 Pattern Alarm Setting

After you press **PROGRAM SETUP** **WAIT/ALARM S.SV SETUP** button in Main Menu to go to (Fig.43) Wait/Alarm S.SV set up display, pressing **NEXT** button to enter into (Fig.56) Pattern alarm set up display.



(Fig.56) Pattern alarm set up screen



(Fig.57) Alarm code selection screen

(Fig.56) is the display of alarm to use from 1 to 4 in pattern. You can select the alarm value set in this display separately, according to Pattern alarm from 1 to 4 per segment in (Fig.45) Program pattern setting display. If you press the alarm code input box to set the alarm sources of temperature or humidity and input your desired code, the alarm code window will appear as shown in the right screen (Fig.57). If you select the alarm button by pressing the **▲** **▼** buttons, it will be entered into the code box of (Fig.56) automatically. To release the set code, you should press the **ALM OFF** button on the right center of (Fig.57).


□ Alarm Type & Code

Code	Alarm Type	Code	Alarm Type	Operation View
1	Upper limit absolute (Tangent)	11	Upper limit absolute (Tangent, Hold)	
2	Lower limit absolute (Tangent)	12	Lower limit absolute (Tangent, Hold)	
3	Upper limit deviation (Tangent)	13	Upper limit deviation (Tangent, Hold)	
4	Lower limit deviation (Tangent)	14	Lower limit deviation (Tangent, Hold)	
5	Upper limit deviation (Reciprocal)	15	Upper limit deviation (Reciprocal, Hold)	
6	Lower limit deviation (Reciprocal)	16	Lower limit deviation (Reciprocal, Hold)	
7	Upper & lower limit deviation	17	Upper & lower limit deviation (Hold)	
8	Within the range of upper & lower limit deviations	18	Within the range of upper & lower limit deviations (Hold)	
9	Upper limit absolute (Reciprocal)	19	Upper limit absolute (Reciprocal, Hold)	
10	Lower limit absolute (Reciprocal)	20	Lower limit absolute (Reciprocal, Hold)	


□: SV □: Alarm SV

5.2.6 Operation start condition setting

The initial setting value is necessary to ascent or descent by the setting value of 1st segment when you start to work with Program control. Select this the initial setting value between Start setting value(S.SV) and Current measurement value(S.PV). Pressing **WAIT/ALARM S.SV SETUP**, **NEXT** buttons in Program setting menu display, Pattern alarm setting display will be shown. Pressing **NEXT** button again In this display, it will be shown to (Fig.58) S.PV Working start setting display.




(Fig.58) S.PV Operaiton start setting display




(Fig.59) S.SV Operation start setting display

Name	Function	Range
Pattern No.	Enter the pattern number to set or select it by pressing the ▲ ▼ button.	1~ 300 pattern
Start mode	S.SV Start the operation based on the SV set in the temperature & humidity S.SV below.	
	S.PV Start the operation based on the current	
T. S.SV	Set to the start SV upon temperature program running.	-100.0 ~ 200.0 [i □]
H. S.SV	Set to the start SV upon humidity program running.	0.0 ~ 100.0 [i □]




(Fig.60) S.SV Operation start mode




(Fig.61) S.PV Operation start mode

5.2.7 Program pattern menu setup



(Fig.62) Program pattern name



(Fig.63) Number input screen

(Fig.62) is the display to enter with selecting Working name in current inputted pattern. Pressing **PROGRAM SETUP**, **PATTERN NAME** buttons in Main Menu go to (Fig.63) Program pattern name set up display. Entering Program title of the desired pattern number by pressing the **▲** **▼** button on the right top side, the input display of (Fig.63) will be shown. Enter the desired pattern number with changing Keyboard by pressing **CHANGE KEYPAD** button.

5.2.8 Pattern/Segment management


(Fig.64) is the display for managing patterns through pattern copy, segment copy and segment initializing. In the left side you should enter the source pattern or segment number used for pattern management. In the right side you should enter the target pattern number of segment

number to be copied. After entering a desired value, you can copy it by pressing **PTN.COPY** **SEG.COPY** button in arrow.

Pattern Clear button on the left center is used for initializing all the internal segments of the pattern entered into the input box above.

Pressing **PTN.COPY**, it will be copied to contents related with every segment in internal pattern. Pressing (Fig.64) Segment

management **SEG.COPY** button, it will copy contents of the original start/End segment copy from a copy start segment. It is possible to copy segment into your desired position by inserting different segment numbers of the right copy when copying segment. (Example : the original 1~6 to the copy 7~12)




(Fig.64) Pattern/Segment management

⚠ Caution


Keep in mind that it is impossible to recover the original contents of the target after copying the pattern/segment. Once you press the **Pattern Clear** button, the original contents of the source cannot be recovered again. After copying pattern by using **PTN.COPY** button, you should make sure that the related parameter is proper setting. (Repeat, Connect, Waiting, Alarm, Start mode, ect)

5.3 Date/Time Reservation Setting

(Fig.65) is display of Date/Time Reservation Setting. After Input current Date/Time by pressing a window of Date/Time input, Press **SET** button.



(Fig.65) Reservation time setting screen




(Fig.66) The 1st running screen of Fix control

⚠ Caution


If you begin to work by pressing **RUN** button during reservation waiting, reservation waiting will be canceled automatically and the operation will start. Likewise, if you start the **RUN/STOP** operation through Contact input(D.I), reservation waiting will be canceled automatically

5.4 Graph/Save Setting

In the Graph axis setting screen (Fig. 67), the time on the X axis means the time per division, and can be designated as 20 seconds to 24 hours according to its internal setting. The Y axis is designed for setting the upper and lower temperature limits from -20 to 200 and its humidity is fixed as 0 to 100[%].



(Fig.67) Graph Setting screen



(Fig.68) Graph display screen

	Division Setting Time (m/s)	Entire Screen Time (h/m/s)
1	00 / 20	00 / 03 / 20
2	01 / 00	00 / 10 / 00
3	02 / 00	00 / 20 / 00
4	03 / 00	00 / 30 / 00
5	04 / 00	00 / 40 / 00
6	05 / 00	00 / 50 / 00
7	06 / 00	01 / 00 / 00
8	07 / 00	01 / 10 / 00
9	08 / 00	01 / 20 / 00
10	09 / 00	01 / 30 / 00
11	10 / 00	01 / 40 / 00
12	20 / 00	01 / 50 / 00

	Division Setting Time (m/s)	Entire Screen Time (h/m/s)
13	00 / 30	05 / 00
14	00 / 40	06 / 40
15	00 / 50	08 / 20
16	01 / 00	10 / 00
17	02 / 00	20v00
18	03v00	30 / 00
19	04 / 00	40 / 00
20	05 / 00	50 / 00
21	06 / 00	60 / 00
22	09 / 00	90 / 00
23	12 / 00	120 / 00
24	24 / 00	240 / 00

Table 3) Time per X axis DIV

As far as the saving operations are concerned, the total 86,400 pieces of information on temperature & humidity (Y/M/D, temperature & humidity SV/PV/MV) under current controlling will be recorded to the internal memory. The saving cycle can be designated as 1 to 360 seconds. Therefore, if the saving cycle is 1 second, it can save for one day. On the other hand, if the saving cycle is 30 seconds, it can save for 30 days.

The optional buttons for saving are shown in the following table.

Button	Name	Function
ALL ON	ALWAYS ON	Save always
RUN ON	RUN ON	Save during controlling only.(Fix/Program)
FIX ON	FIX-RUN ON	Save during fixed-mode controlling only
Prog ON	Program-RUN ON	save during program mode controlling only
Buf.Init	Internal Buffer initialize	Delete/Initialize Saved Contents in internal memory

TH500 present USB connection function to send saved data to PC. According to Save Sequence & Save Operation Mode set in (Fig.67) Graph Setting display, Data stored in internal memory become mass difficult to transfer with low-speedy connection (Max. 115,200BPS) interface like RS232, RS422/485. If you send by using USB connection in that time, it is possible to send to PC within a few second.

(Fig.69) is the display of USB Up-loader software presented by HANYOUNG NUX CO., LTD. When USB connector is connected, Device connecting status is indicated, **Connected** in blue and **LOG DATA TRANSMIT TO USB.** button is activated. Pressing **Send** button, you can receive every Measure/control value recorded in TH500 through USB. Transferred date is stored in the folder of **C:\TH500_DATA**. Because all saved Data file is in text mode, you can see the content of saved data file with any editor, word-processor or Excel. It is possible to see a graph by using Graph Viewer program presented.


Caution 1. If you turn off, all contents will be deleted because the value of saved measurement & control is saved in Volatile Memory(SDRAM).

Caution 2. When you connect USB, you must use USB A-B connector cable.

Caution 3. The USB Plug & Play function of some PCs may have errors upon PC booting. Therefore, it is necessary to connect USB connector after PC booting. After PC booting, you are free to connect USB connector.



(Fig.69) USB Up-loader Utility




(Fig.70) Graphic viewer

6. System Setting


Caution

Caution : System set up is a pre-installed basic setting condition so you are requested attention when you change it.

If you push **MENU** on operation screen, Main menu screen will be displayed. And if you push "Main Menu", password screen will be displayed (initial value: 0). and then you can enter system setting screen, after pushing **ENT** on screen.



(Fig.71) Main menu screen




(Fig.72) System set up menu screen


6.1 Sensor type setting

Our temperature and humidity controller (Model # TH500) support various outputs and inputs so you need to set output and input information before using this controller. On the operation screen, push screen as following,

MENU → **Main MENU**



(Fig.73) Temperature sensor setting screen



(Fig.74) Humidity sensor setting screen

● Sensor type

Set up according to sensor type. If the sensor type is a DRY_{FB} WET bulb type and each is RTD (Resistance Temperature Detector - Pt100 Ω), please select .

If you use electronic humidity sensor (Model # EE99), temperature sensor type will be  and humidity sensor type will be  (But in case of S.C.R Out terminal will be 250 Ω and 1% resistance need to be contacted to sensor input terminal.

● Input range

Regarding sensor input range, you can use initial value. The initial setting for temperature value is -100...200 μ and humidity value is 0...100% R.H. If you use electronic humidity sensor (Model # EE99), please set up input range to 1-5V d.c and contact resistance (250 Ω 1% below) to the both of input terminals.

● Scale setting

If you select DC voltage (V d.c), please enter proper scale value. If you enter 1-5 V d.c and display range is 0~100, please set up scale setting value from 0 to 100.

● Sensor Bias

The sensor bias revises deviation that is caused by many reasons.

● LPF setting


LPF (Low Pass Filter) setting When process value is chattering due to inflow of noises through input sensor, user can input proptime.

Dry T. Range	Set up Dry / Web temperature range.
Dry Temp.	Displays Dry bulb temperature
Web Temp	Displays Wet bulb temperature (Gauze have to be removed)
Rel. Humidity	Displays relative humidity (% R.H.)
D / W Adjust.	Press Dry/Wet bulb ADJ and it shows the temperature difference between dir bulb and web bulb. It's very important to correct Dry/Web bulb because relative humidity measurement is based on the temperature difference between two sensors.
Adjust mode	If you push setting, correction will be started


 **Caution**

Please remove gauze in the web bulb sensor before correction. And also start correction after stabilization of the process value. Please recover gauze after correction.

T. SV range	In order to prevent users mistake the Temperature SV range can be restrictive as much as wanted range.
H. SV range	In order to prevent users mistake the humidity SV range can be restrictive as much as wanted range.
Temp. Res	Temperature process vale and SV can select 0.01 μ or 0.1 $^{\circ}$ C
Burn out wait time	Set up delayed action time after detecting sensor loof brake.
A/T Button	It shows or hides Auto Tuning button in operation screen.




(Fig.75) Dry Wet bulb sensor correction screen




(Fig.76) Range setting screen

6.2 Control output setting




(Fig.77) Temperature control output setting



(Fig.78) Humidity control output setting


Control output for Temperature and Humidity needs to be set individually as following.

T. out type	Select and use S.S.R or S.C.R (4-20mA d.c). Select according to the equipment (Initial value : S.S.R)
T. SSR out period	You can set up when you select S.S.R output. Output cycle means On/Off working time in the proportional band.(Initial Value : 2 seconds)
T. out direct	Select cooling control (direct movement) or heating control(inverse movement) (Initial Value : Inverse movement)
T. out range	You can control output and selection range is -5%(3.2 mA d.c) 0.5 %(20.8 mA d.c) (Initial Value : 100 %)



(Fig.79) S.S.R pulse output


It is an example for S.S.R output from 20% to 100% output range. Base on cycles of control output, MV (Manipulated Variable) is changed to Duty.




(Fig.80) S.C.R output

6.3 Retransmission output setting

Retransmission output can be selected from output set up 3 and output set up 4.



(Fig.81) Temperature retransmission output setting screen.



(Fig.82) Humidity retransmission output setting screen.


● Temperature retransmission output (Output setup 3)

T. Source	Select type of RET (Retransmission output) for temperature. It is used for input in recorder etc. output signal is 4-20 mA dc and select one among PV (Process Value), MV (Manipulated Value), SV (Setting Value).
T. Range	Scale value against temperature output range will be selected 4-20 mA d.c. But if MV selected, output will be the percentage of setting value against 4-20 mA d.c. It means if you select 50 %, output will be 12 mA d.c.
Output Bias	In order to delete deviation value of retransmission output, input current offset.
S. Burnout Output	In case of sensor loop brake, select between retransmission output current Sensor loop break output. Select 0.0 mA dc. or 4.0 mA d.c

● Humidity retransmission output setting (Output set up 4)

H. Source	Select type of RET (Retransmission output) against Humidity. It is used for input in recorder etc. output signal is 4-20 mA dc and select one among PV (Process Value), MV (Manipulated Value), SV (Setting Value).
H. Range	Scale value against temperature output range will be selected 4 - 20 mA d.c. But if MV selected, output will be the percentage of setting value against 4 - 20 mA d.c. It means if you select 50 %, output will be 12 mA d.c.
Output Bias	In order to delete deviation value of retransmission output, input current offset.
S. Burnout Out	Sensor loop break output. Select 0.0 mA dc. or 4.0 mA d.c


6.4 Inner Signal and Alarm setting



(Fig.83) Inner Signal setting screen

Time Signal is related with segment and Time but Inner Signal is used for signal output of temperature and humidity. So Inner Signal is not related with segment section.


Setting item	Function	Initial setting
(I/S) Number	Directly input it by pushing Inner Signal number or select it by push button.	
(I/S) Item setting	Select Inner Signal item (Temperature or Humidity)	Temperature
(I/S) Type setting	TSV (Target Set Value): Operate base on target setting value NSV (Now Set Value): Operate base on current setting value P.V1: Operate base on process value of action range 'L' and 'H'. P.V2: Operate base on process value that are related with setting value and deviation	TSV
(I/S) Operation range	setting value. Setting temperature and humidity range of Inner Signal	-100...200 °C
(I/S) Range direction	Setting application range of Inner Signal	Internal range
(I/S) Delay time	Operate delay time of Inner Signal	-



(Fig.84) Example of Inner Signal setting (NSV)

(Fig.85) Example of Inner Signal setting (TSV)

Fig. 84 is an example for Inner Signal setting (NSV). Setting Inner Signal 1~3 & 8 for temperature, internal range, NSV, -> According to change of Set value (SV), Inner Signal turn ON/OFF. Fig. 85 is an example for Inner Signal Setting (TSV) Setting Inner Signal 1~3 & 8 for temperature, Internal range, TSV -> Base on TSV (Target Set Value), Inner Signal turn ON/OFF Fig. 86 is an example for Inner Signal Setting (PV1) Setting Inner Signal 1~3 & 8 for temperature, PV1, Internal range Fig. 87 is an example for Inner Signal setting (PV2) Setting Inner Signal 1~3 & 8 for temperature, PV2



(Fig.86) Example of Inner Signal setting (PV1)


(Fig.87) Example of Inner Signal setting (PV2)

● System alarm setting


This is a setting screen for Temperature and Humidity alarm.

If you push **System alarm setup** on the System set up menu screen, Inner signal set up screen will be displayed. And then, if you push **NEXT**, System alarm set up screen will be displayed (Fig. 88).

1. Establish a standard for alarm setting value among Temperature and Humidity
2. If you push alarm code select button, System alarm code setting will be displayed as Fig. 89.
3. Push **▲** **▼** button and select proper alarm type as Fig. 88.
4. If you want to cancel selected code, please push **ALM OFF** on the left side.
5. And then set, alarm value and Hysteresis.



(Fig.88) System alarm setting screen



(Fig.89) System alarm code screen

4 Buttons on system alarm screen are for the operate condition of alarm setting.


Setting item	Description
ALL ON	All ways turn on alarm
RUN ON	Maintain alarm on operation
FIX ON	Maintain alarm on fixed control operation
Prog ON	Maintain alarm on program control operation

6.5 P.I.D Setting


The TH500 has total 16 PID ZONES. As following four temperature zones and four humidity zones are combined with each other, so you can control temperature and humidity with the optimized PID value. User can change the zone boundary of temperature and humidity, freely.

Temp.Zone Humi.Zone	-100 ≤ Temp.SV ≤ TZ ₁	TZ ₁ < Temp.SV ≤ TZ ₂	TZ ₂ < Temp.SV ≤ TZ ₃	TZ ₃ < Temp.SV ≤ TZ ₄
0 ≤ Humi.SV ≤ HZ ₁	ZONE 1	ZONE 2	ZONE 3	ZONE 4
HZ ₁ < Humi.SV ≤ HZ ₂	ZONE 5	ZONE 6	ZONE 7	ZONE 8
HZ ₂ < Humi.SV ≤ HZ ₃	ZONE 9	ZONE 10	ZONE 11	ZONE 12
HZ ₃ < Humi.SV ≤ HZ ₄	ZONE 13	ZONE 14	ZONE 15	ZONE 16

TZ : Temp.Zone, HZ : Humi.Zone



(Fig.90) Temp. & Humi P.I.D Zone Set up




(Fig.91) Temp. & Humi P.I.D Set up

The **AUTO** / **MANUAL** buttons on the left side of the PID set up screen (Fig. 90) are automatic & the manual setting. For example, If you push **AUTO** and start Auto-tuning at 80 °C Temp. PID value will be applied in the zone 3,7,11 & zone 15. And if you do auto-tuning of Humi. at 75%, Humi. P.I.D value will be applied in the zone 11. In case of Manual mode, Please refer to just SV in the zone set according to the manual.

When you check the value of P.I.D or input it manually, please push zone button which you want, And then move to 'Temp & Humi P.I.D Set up as like Fig. 91. If you want to use only ON/OFF control, you can put 20 in the P.I.D values.


Temp. & Humi. A/T GAIN on the above in the left side is a constant value which is applied to the each item of P.I.D during P.I.D carries out on operation. The setting range is from 0.0 to 10.0 (Initial value : 1.00). It is used that optimize P.I.D numerical value automatically operated after P.I.D Auto-tuning more delicate manually. According to the variation of A/T GAIN value, the variation of Control feature is same with (Fig. 92).




(Fig.92) Variation characteristic control by controlling Auto-tuning GAIN(PV)

Term	Description
GAIN < 1.0	Totally Response speed is faster, but Hunting occurs time by operating Differentiation & Integration control which are stronger more than Auto-tuning PID value.
GAIN = 1.0	Use Auto-tuning PID value as it stands. Totally Response speed is slower, but
GAIN > 1.0	Overshoot is decreased time by operating Differentiation & Integration control which are smaller more than Auto-tuning PID value. It grows more stable situation.


Name	Description
P (Proportional)	<ul style="list-style-type: none"> Set a proportional value. Its unit is F/S vs. [%]. If the P-Band is wide, the MV output becomes slow. Therefore, it takes longer for the PV to reach the SV. If the P-Band is narrow, the MV becomes sensitive. Therefore, the PV approaches the SV faster, but fails to converge due to continuous hunting.
I (Integral)	<ul style="list-style-type: none"> Set an integration time. Its unit is the hour [second]. The P control only is not enough to make the PV and the SV consistent, generating a variation (offset). In this case, the integration reduces the
D (Derivative)	<ul style="list-style-type: none"> Deviation. If the integration time gets too longer, it will converge later. If the integration time gets shorter, it will hunt continuously or even diverge. Set a derivative time. Its unit is the hour [second]. It restrains the drastic change in PV by calculating the PV variation every moment and producing the output of its proportional MV.
HYS.(Hysteresis)	Set Hysteresis value when Auto tuning or ON/OFF control.




(Fig.93) On/Off control



(Fig.94) Proportional control (P control)




(Fig.95) Proportion (P) and Proportional Integration (P+I) control




(Fig.96) Proportional Integration (P+I) control

6.6 D/I Configuration Setting

It offers the total 8 points for Digital Input (D/I), and receive external input (Active Low). Each D/I input you can enter your desired name based on the combination of Korean/English/Number/Sign (Fig. 98). As for D/I #1~8, you can assign the operation function to three types (RUN/STOP, STEP, HOLD) related to controller operation on the screen of (Fig. 97) D/I setting 1.



(Fig.97) D/I setting 1



(Fig.98) D/I setting 2


User can set up HIGH / LOW operation for these three types. As the LEVEL input, the RUN/STOP and HOLD input should maintain their levels continuously. As the EDGE input, the STEP operation runs once according to its setting once upon H->L or L->H. You should continuously enter H and L in order to keep on STEP operation.

⚠ Caution

1. In case of RUN/STOP, STEP and HOLD operation input, it is impossible to assign the D/I number redundantly. In addition, if the STEP and HOLD input come in at the same time, it ignores the STEP input, but handles the HOLD input only.
2. External D. I always displays a screen & it is taken in the interior according to the situation of input irrespective of control action (Running or Stop).

Name	Function
RUN/STOP (LEVEL Input)	Start or end the assigned D/I input signal according to the operation mode (H/L) set.
STEP (EDGE Input)	In case of running in program control mode, perform the STEP operation (go to the next SEG. by force) for the assigned D/I input signal according to the operation mode (H/L) set.
HOLD (LEVEL Input)	In case of running in program control mode, perform the HOLD operation (hold the current SEG. operation unlimitedly regardless of set time) for the assigned D/I input signal according to the operation mode (H/L) set.

The D/I input often indicates external errors, so it is sometimes necessary to stop the system control not with normal RUN/STOP but with D/I input. At that time, the D/I number assigned to operation out of D/I #1 to 8 turns into gray and does not run. As for the rest of D/I numbers except the assigned numbers, it is possible to set them in the D/I setting 3 screen (Fig. 99).




(Fig.99) System reset setting


Name	Function
RST	In case of D/I input, it is the button for setting the system RESET (End). Only if you press this button, the waiting time becomes valid.
Waiting time (sec)	It resets (end) the system in a waiting time while the system RESET button is pressed.

6.7 D/O Configuration Setting


The D/O configuration setting refers to the screen for assigning the various signals within the system to RELAY output and O/D output. Here, the signals assigned and connected are displayed through the actual terminal. The D/O assignment is allowed to be redundant except special cases, so it is necessary to assign and enter the RELAY and O/C carefully. The D/O configuration setting 1, 2 (Fig. 100, 101) refers to the screen that assigns Inner Signal and Time Signal to RELAY output and O/C output respectively.




(Fig.100) DO Configuration Setting 1 (Inner Signal)



(Fig.101) DO Configuration Setting 2 (Time Signal)



(Fig.102) DO Configuration Setting 3




(Fig.103) DO Configuration Setting 4

The D/O configuration setting 3 [Fig. 102] refers to the screen for assigning the screen-displayed functions to RELAY output and O/C output. In the alarm #1 to 4, both system and pattern alarms are used together. (System alarm #n and pattern alarm #n run in logical OR.)

Name	Function
Alarm (#1~#4)	System and pattern alarms. Assign the #1~#4 output
Sensor Disconnection	Output assignment upon sensor disconnection
T.RUN	Output assignment upon temperature control
H.RUN	Output assignment upon humidity control
RUN/STOP	Output assignment under RUN
WAIT	Output assignment for WAIT operation
HOLD	Output assignment for HOLD operation


DO Configuration Setting 4(Fig.103) is used when each setting value(SV) of Temp. & Humi. In the section of temperature & humidity Up/Hold/Down. Each setting input value of Set Item operates like (Fig. 104).



(Fig.104) Output by temperature Up/Hold/Down setting

Setting Item	Description
Temp. & Humi. Up section	Input the minus value of Temp. & Humi. in the target of setting value
Temp. & Humi. Down section	Input the plus value of Temp. & Humi. in the target of setting value
Temp. & Humi. Hold section	Input the holding time of Relay or O/C output with in segment time


(Fig.104) shows an example of displaying either Relay or O/C output corresponding to the temperature Up/Hold/Down setting of temperature and humidity SV in the program control mode. In case of adjusting the Up setting temperature, Hold setting temperature and Down setting temperature to -10 ; □ 2 minute and 20 ; □ respectively, it indicates the timing ON with the assigned Relay or O/C output.




(Fig.105) DO Configuration Setting 5

Item	Description
D/I ERROR [Min]	In case of D/I input, its output becomes ON for a setting time. If the RUN/STOP, STEP and HOLD function input is set, its D/I will be excluded.
PROG. End [Min]	Once the program control ends, its output becomes ON for a setting time.
Delay signal 1 [sec]	After the I/S #1 is displayed, its output becomes ON after a delay [second] for a setting time.
Delay signal 2 [sec]	After the I/S #1 is displayed, its output becomes ON after a delay [minute] for a setting time. (However, the delay signal 2 is displayed only if the delay signal 1 becomes ON.)

6.8 Communication Setting



(Fig.106) Communication Parameter Setting (RS232)



(Fig.107) Communication Protocol (RS422/485)

The communication setting refers to the screen for setting either RS232 or RS422/485 parameters to communicate with the device that supports PC or other serials. You can change it with the Up/Down arrow buttons, and can enter the local device number and response time by selecting the input box on your own. Because RS232C/485 communication supports 4 lines (RX+, RX-, TX+, TX-) in hardware and the type of Half-Duplex in software, if you want high speed communication, you should connect into 4 lines. In other case, if you want a simple connection, you can use 2 lines by connecting RX+ with TX+ & do RX- with TX-. If you want a simple connection by connecting 4 lines, you can use 2 lines by connecting RX+ with TX+ & doing RX- with TX-.

Name	Function	Range
Communication protocol	Set the communication protocol. The protocol runs according to the HANYOUNG NUX-designed format.	PCLINK / PCLINK+CRC
Communication speed (BPS)	Set the communication speed (BPS). You can select one out of 600/1200/2400/4800/9600/19200/38400 /57600/115200.	1,200 ~ 115,200
Parity bit	Set the parity bit.	NONE / EVEN / ODD
Stop bit	Set the stop bit.	1 / 2
Date length	Set the data length.	5 / 6 / 7 / 8
Local device No.	Set the device number to be used in the system. It is used as its own device number when forming the serial network.	1 ~ 999
Response time [ms]	Select the inter-Byte delay time when sending data. Used when the target equipment to receive runs at a low speed.	0 ~ 1,000 (100 us)

6.9 Other Setting



(Fig.108) Other Setting


Name	Function
Language	Select system language. It supports Korean and English.
Password change	Change system password. You should enter your password in the unit of four numbers and do so twice for confirmation.
User information	Enter the user information to indicate upon the initial system activation. You can enter 29 letters of English/Number/Sign or 14 letters of Korean on one line.

7. Simple Example


HANYOUNG NUX is Temperature Humidity Controller (Model: TH500) is consisted of Operation screen, Operation Setting screen, System Setting screen. You can select structural elements in the System Setting.

System installation company such as environment test chamber manufacturer etc already finished the system setting when they taking its product out of warehouse. So users do not have to do system setting additionally. Users can set up humidity-temperature simply through Operation Setting.

7.1 Input / Output Setting




(Fig.109) Temperature sensor setting screen




(Fig.110) Humidity sensor setting screen

7.1.1 Sensor Input Setting

Setting Item	Explanation
Sensor Type	Set up according to input sensor type. If sensor type is a dry or web bulb respectively and RTD (Pt 100 \pm) type, select RTD. If you use electronic humidity sensor (Our Model EE99), you should set up temperature sensor as R.T.D and humidity sensor as V d.c
Input Range	Set up input range of the sensor(s), Generally you can use initial value and initial value of temperature is -100...200 \pm humidity is 0...100% R.H. If you use electronic humidity sensor (Our model EE99), after setting up input range as 1-5V, connect resistance (250 \pm below 1%) into two humidity sensor input terminals.
Scaling Setting	When selecting V d.c, set up suitable scale. In case of 1~5V input and display range: 0~100, set up scaling setting as 0~100.
Sensor Deviation	Sensor deviation corrects the deviation of sensor which is caused by several reasons.
LPF	Low Pass Filter selects suitable time when processed value is chattering due to inflowing of noise through input sensor line.



(Fig.111) Dry/Wet bulb sensor correction screen



(Fig.112) Range setting screen

7.1.2 Correct Dry/Web bulb sensor

Setting	Explanation
Dry Bulb Temp. Range	Set up dry/web bulb temperature range.
Dry Bulb Temp.	Displays temperature of dry bulb temp.
Wet Bulb Temp.	Displays temperature of wet bulb temp.(removal gauze)
Relative humidity	Displays relative humidity (% R.H.)
Correction of Dry/Wet Bulb	Press Dry/Wet Bulb ADJ and it shows the temperature difference between dry bulb & wet bulb. It's very important to correct Dry/Wet Bulb because relative humidity measurement is based on the temp. difference between two sensors.
Correction Mode	Correction will be performed when pressing it.




Caution

Before correction, please remove gauze in the wet bulb sensor and put into correction mode when measurement value of dry/wet bulb is stabilized.


7.1.3 Range Setting

Temp. SV Range	In order to prevent user's input setting mistake, Input temp.range when restricting temp. SV within its desired range.
Humidity SV Range	
Temp. resolution	In order to prevent user's input setting mistake, Input humidity range when restricting humidity. SV within its desired range.
Waiting time in Loof Brake	Select Temp. process value and SV as 0.01 \pm or 0.1 \pm
Display A/T button	Set up delayed action time after detecting sensor loof brake.
	It shows or hides Auto Tuning button in Operation Screen.

7.2 Output Setting



(Fig.113) Control output setting



(Fig.114) Retransmission output setting

7.2.1 Control Output Setting


Type of Temp. Output	Output Select and use S.S.R or S.C.R (4-20mA d.c). Select according to equipment. (Initial Value : S.S.R)
Output cycle of Temp.S.S.R	RYou can set up when you select S.S.R output. Output cycle means On/Off working time in the proportional band.(Initial Value : 2 seconds)
Direction of Temp.output	Select cooling control (direct movement) or heating control(inverse movement) (Initial Value : Inverse movement)
Range of Temp. output	You can control output and selection range : -5%(3.2mA d.c) . . . 0.5%(20.8mA d.c) (Initial Value : 100%)
Temp. output A/T GAIN	It is a Constant Value applied to each performance when P.I.D computed. Selection range is 0.0~10.0 (Initial Value : 1.00)

7.2.2 Retransmission Output Setting


Temp. output Type	Select type of RET(Retransmission output) against temperature. It is used as input in the recorder etc. output signal is 4-20mA dc and select one among PV(Process Value), MV(Manipulated Value), SV(Setting Value).
Temp. output Range	Scale value against temp. output range will be selected 4-20mA d.c. But if MV selected, output will be the percentage of setting value against 4-20mA d.c. It means if you select 50%, output will be 12mA d.c.
Temp. output Deviation	In order to delete deviation value of retransmission
Sensor Loof Brake Output	output, input current offset. In case of sensor loof brake, select between retransmission output current between 0.0mA d.c and 4.0mA d.c

i□Humidity setting method is the same as temperature setting method

7.3 Inner Signal Setting



(Fig.115) Inner signal setting screen



(Fig.116) DO Configuration Allocation screen

When controlling refrigerator and dehumidifier separately by external switch, it can be used generally with input-output setting only. But in case it needs to control (On/Off) refrigerator & dehumidifier under desired temperature and humidity, it's convenient to use Inner Signal. Please refer to the below example, select setting and use it.

(Example 1) Control refrigerator & dehumidifier automatically

Inner Signal No.	Signal Subject :	Signal Type & Range	Delayed Time	Output Allocation(D.O)
I/S No.1	Temperature Range : -100~30 i□	Type : TSV Direction : Within Range	1 minute	Connect refrigerator to 5th Relay
I/S No.2	Subject : Humidity Range : 0~70%	Type : TSV Direction : Within Range	10 seconds	Connect dehumidifier to 6th Relay

(Example 2) Control refrigerator 1,2 & dehumidifier automatically (Use I/S 1~3)

Inner Signal No.	Signal Subject :	Signal Type & Range	Delayed Time	Output Allocation(D.O)
I/S No.1	Temperature Range : -100~30 i□	Type : TSV Direction : Within Range	1 minute	Connect 1st refrigerator to 5th Relay
I/S No.2	Subject : humidity Range : 0~70%	Type : TSV Direction : Within Range	10 seconds	Connect dehumidifier to 6th Relay
I/S No.2	Subject : Temperature Range : -100~50 i□	Type : TSV Direction : Within Range	5 seconds	Connect 2nd refrigerator to 7th Relay



Caution

You have to select temperature range of refrigerator according to its specification. If you set up too high temperature, it may cause malfunction of refrigerator.

7.4 Fix Control


7.4.1 Select how to operate

In order to operate Fix Control, firstly select operating method as fix control.


Press **MENU** button on the operation screen and move to main menu screen.

Press Function set up and it moves to Function Set up 1 screen.

On this screen, press **FIXRUN** button and select fix control. And then, press **ESC** button two times and move to operation screen 1 in the fix control.




(Fig.117) Function Set up menu screen




(Fig.118) Function Set up 1 screen

7.4.2. Temperature & Humidity Control Value Setting

Press temp. & humidity setting and set up desired setting value. (After set up number, please press ENT button in order to finish setting finally.) Press **ESC** button and it will be back to the 1st Operation Stop Screen of Fix Control (Fig.119)



(Fig.119) The 1st running screen of Fix control (stop screen)



(Fig.120) The 1st running screen of Fix control (run screen)

7.4.3 Operate and STOP of Fix Control

In the 1st running screen of Fix control(stop screen) (Fig.119), you can check its operation by pressing **RUN** button. Press **YES** button leads it to start operation. If you press **STOP** button in the (Fig. 120), operation will be stopped when pressing **YES** button in the displayed processing verification screen.

7.4.4 Start Auto Tuning


Although it starts fix control operation according to users' setting value, if you do not perform Auto Tuning, P.I.D control will be applied in accordance with its initial value at the delivery of goods. Therefore it will be better to perform Auto Tuning in order to get good control performance. To start Auto Tuning, press Auto Tuning button **TAT** at the bottom of (Fig. 120). When **TAT** button flickering, it shows that Auto Tuning is being performed. After Auto Tuning finished, Auto Tuning values will be set up automatically and it stops flickering. Same as temperature Auto Tuning **TAT**, perform auto tuning of humidity by pressing **HAT** button.

7.5 Program Control


7.5.1 Selection of Program Control

Firstly select operation method as a program control in order to perform program control. Press **MENU** button under the status of operation screen and move to Main Menu screen. After pressing **FUNCTION SETUP** button, it moves to Function set up 1 screen. On this screen, press **PROGRAM** button and select program control. And then, press **ESC** button one time and move to Main Menu screen.

In the function setting main screen (Fig. 121), press **PROGRAM SETUP** and it shows PROGRAM set up menu screen like (Fig. 123) and it is consisted of 5 buttons. Press each button and select setting respectively.




(Fig.121) Main Menu screen




(Fig.122) Function Set up 1 screen

7. 5. 2 Pattern Setting

Press **PATTERN SETUP** button in the program setting menu screen, it displays program pattern setting screen (Fig.124). Under this screen, select number 1 pattern by pressing pattern number setting window. Press window of temp.setting value, humidity setting value, operating time and then set up relevant segments.



(Fig.123) Program Set up menu screen



(Fig.124) Program pattern Set up screen

Explanation of Program Pattern Setting Screen

Setting	Explanation	Range
Pattern No.	Input pattern no. directly or select it by using <input type="button" value="↓"/> <input type="button" value="↑"/> button	1...300 pattern
SEG.page	Press Segment Page Shifting button(<input type="button" value="↓"/> <input type="button" value="↑"/>)and it moves to 4 segment per each shifting	
Temp. SV	Press setting screen and set up setting value of temperature of the segment.	-100...200 i□
Humidity SV	Press setting screen and set up setting value of humidity of the segment.	0...1000 %
Time	Set up operation time of the segment	0...255hours and 59minutes
Standby	Select function of Standby Operation which was set up in the Standby Operation Setting Screen.	ON/OFF
T.S	Select Time Signal which works at the segment	
Pattern Alarm	Among 4 Alarms which was set up in the Patter Alarm Setting Screen, select operation respectively. Pattern Alarm Selection Screen (Fig. 47)	1...4 respectively ON/OFF

Explanation of Program Pattern Setting Screen

Operating Seg.	Contents of setting	Remark
SEG.No.001	Under the Temp 25 i□ Humidity 80% set up temp. & humidity segment for one minute.	Consider connected pattern as ne and repeat it infinitely
SEG.No.002	Under the Temp 25 i□ Humidity 80% set up temp. & humidity maintenance segment for one minute.	
SEG.No.003	Under the Temp 50 i□ Humidity 60%, temp. rise & humidity fall for one minute.	
SEG.No.004	Under the Temp 50 i□ Humidity 60%, temp. rise & humidity fall for one minute.	
SEG.No.005	Under the Temp 75 i□ Humidity 40% set up temp rise & humidity fall segment for one minute.	
SEG.No.006	Under the Temp 75 i□ Humidity 40% set up temp. & humidity maintenance segment for one minute.	

7.5.3. Pattern Setting

In the picture of Pattern Repeat/Connection Setting screen (Fig. 125), set up connection pattern as 1 (it' s own number). In the Program Control 1st Operation Stop screen (Fig. 126), please input pattern no. & segment no. respectively into the Program Start Pattern & Start Segment Setting Screen in the pattern. After pressing **RUN** button, it starts operation of program control. In order to stop Program Control, press **STOP** button on the right-bottom side of Program Control 1st Operation Stop screen. (Fig. 127). In addition, operation screens of Program Control are as follows: (Fig. 127), (Fig. 128), (Fig. 129).


8. Specification

8.1 Input


Input	Dry ψ -Humidity sensor	RTD (resistance temperature detector (Pt 100 ψ) DIN 43760)
	Digital Temperature	Temperature sensor: RTD (Pt 100 ψ)
	ψ -Humidity sensor (EE99)	Humidity sensor: Director current (4 - 20 mA d.c) Input resistor around 1 ψ
	Sampling cycle	500 mm
Range	Temperature	-100.00 ~ 200.00 ψ
	Humidity	0.0 ~ 100.0 % R.H
Accuracy	Temperature	\pm 0.1 % of Full Scale
	Humidity	\pm 1 % of Full Scale
Contact input	1a 4point x 2 (total 8 point) maximum 8 V d.c 10 mA d.c	

8.2 Output


Control Output	SSR	ON : 24 V d.c Pulse voltage (Over 800 ψ load resistance) OFF: Below 0.1 V d.c cycle time : 1 ~ 1000 second
		S.C.R
Retransmission Output	Temperature	4 - 20 mA d.c (Below 800 ψ load resistance)
	Humidity	PV/MV/SV (Internal selection)
	Accuracy	0.025 % of Full Scale (resolution: Around 4,000)
	Renewal Time	5000 ms
Digital Output	Contact output	N.O: 30 V d.c, 5 A, 250 V d.c : 5 A N.O: 30 V d.c, 1 A, 250 V d.c : 5 A
	Open collector output	24 V d.c 300 mA d.c Max.




(Fig.125) Pattern repeat / Link Set up screen




(Fig.126) The 1st running screen of program control(stop screen)



(Fig.127) The 1st running screen of program control(run screen)



(Fig.128) The 2nd running screen of program control



(Fig.129) Graph display screen

8.3 Communication type

Apply range	USB V1.1, EIA-RS232C, EIA-RS485/422	
Number of devices (Max.)	EIA-RS232C	1:1
	EIA-RS485/422	1:32 (Address 1~999)
Communication type	EIA-RS232C	Full duplex mode
	EIA-RS485/422	4 ways half duplex mode
Synchronization	USB V1.1	Around 100 m
	EIA-RS232C	Around 100 m
	EIA-RS485/422	Around 1.2 km
Communication distance	USB V1.1	Around 1M bps
	EIA-RS232C	1200/2400/4800/9600/19200/38400/57600/115200
	EIA-RS485/422	1200/2400/4800/9600
Communication speed	EIA-RS232C	7/8 bits
	EIA-RS485/422	
Data length	EIA-RS232C EIA-RS485/422	NONE/EVEN/ODD
Parity bit	EIA-RS232C EIA-RS485/422	1/2 bit(s)
Stop bit Communication protocol	USB V1.1	Bulk MODE
	EIA-RS232C	PC LINK / PC LINK + CRC
	EIA-RS485/422	PC LINK / PC LINK + CRC
Communication respond time	EIA-RS232C EIA-RS485/422	0-999 ms

8.4 Power supply

Power Supply Voltage	100 ~ 200 V a.c (Change rate of voltage $\pm 10\%$)	
Frequency	50 ~ 60 Hz	
Power Consumption	Max. 20 W below	
Insulation Resistance	Between primary terminal and secondary terminal	500 V d.c /
	Between Primary , Secondary terminal and ground	20 Ω
Dielectric Strength	Between primary terminal and secondary terminal	2500 V a.c 50~
	Between Primary , Secondary terminal and ground	60 Hz for 1 minute
Power supply for Sensor	24 V d.c 10 W Max.	

8.5 Function

Screen	5.7 Inch Color STN-LCD Touch screen	
Bias	Temperature: -100.00 ~ 100.00 ($\pm 1^\circ$)	
	Humidity: -100.0 ~ 100.0 (% R.H.)	
Scaling	When turn on power, free scaling set up	
LPF	2 ~ 180 sec.	
Pattern	300 patterns	
Segment	6,000 segments (100 segments are available in each pattern)	
PID Group	Temperature 16 zone + Humidity 16 zone	
Auto Tuning	According to SV, AT is operating	
Proportional Band (P)	0.00 ~ 100.00(%) (When proportional band is 0.00, ON/OFF control)	
Integral Time (I)	0.0 ~ 6,000 sec (0.00 OFF, I.D Time 0.00 -> P control)	
Derivative Time	0.0 ~ 6,000 sec (0.00 OFF, I.D Time 0.00 -> P control)	
ON/OFF Control	Proportional Band (P) is 0	
Direct/Reverse action	Select Direct or Reverse action in control output	
ON/OFF Hysteresis	0.1 ~ 300.0 ($\pm 1^\circ$) (In case of Humidity, Temperature of Humidity or conversion value)	
Fuzzy	Select ON/OFF	
Retransmission output	4-20 mA d.c 2 points (Temperature, Humidity) Select PV/MV/SV	
Alarm	System alarm 8 points, 8 points for each pattern	
Alarm type	High-Low / Low deviation alarm etc 20 types of alarms	
Alarm setting	Process alarm	Temperature:-100.00 ~ 200.00 ($\pm 1^\circ$), Humidity: 0.0 ~ 100.0 (%)
	Deviation alarm	Temperature:-300.00 ~ 300.00 ($\pm 1^\circ$), Humidity: -100.0 ~ 100.0 (%)
Hysteresis	0.1 ~ 100.0(%)	
Memory for	Internal Flash or SDRAM memory, Temperature-Humidity each	
interruption of electric power	Memory type	86,400 point
	Memory function	Program information & SV backup and restoration, Temperature-Humidity setting, PV save

8.6 Operation Environment

Setting surroundings	Consecutive Vibration	Vibration width : Below 1.2 mm (5 ~ 14 Hz)
	Consecutive Vibration	Below 4.9 m/ s ² (4 ~ 150 Hz)
	Short time Vibration	Below 14.7 m/ s ² 15 sec. (each 3 direction)
	Impact	Below 147 m/ s ² 11 ms (each 6 direction and 3 times)
Conditions for Normal Operation	Temperature	0 ~ 50 i□
	Humidity	20~90 % R.H (No icing)
	Magnetic Range	Below 400 AT/m
	Warming-up Time	More than 10 minutes
Effect of Temperature in the surrounding environment	R.T.D	Below ± 0.02 i□ i□
	Analogue Output	Below ± 0.02% / F.S / i□

8.7 Transportation and Storage conditions

Temperature	-25 ~ 70 i□
Humidity	5 ~ 95 % R.H (No icing)
Impact	After packing, fall from less than 1m